




RHINO-RACK QMFK01

| Item | Component Name | Qty | Part No. |
|------|------------------|-----|----------|
| 1 | M6 Nut with Foam | 8 | N018 |
| 2 | Instructions | 1 | R577 |



1
Move to the tub of the vehicle. Remove the rubber plugs closest to the cabin in the tracks on either side of the tub.

2
With the plugs removed, slide four M6 nuts in both sides, foam side down.

3
QMDHD05 Fit Kit.
Fit the RLT600 Leg Kit as shown in their instructions. QMHD05 must be purchased to fit Heavy Duty Bars.

Issue: 01


Document No: R577

Prepared: Kayle Everett



RHINO-RACK QMFK01

| Item | Component Name | Qty | Part No. |
|------|------------------|-----|----------|
| 1 | M6 Nut with Foam | 8 | N018 |
| 2 | Instructions | 1 | R577 |



1
Move to the tub of the vehicle. Remove the rubber plugs closest to the cabin in the tracks on either side of the tub.

2
With the plugs removed, slide four M6 nuts in both sides, foam side down.

3
QMDHD05 Fit Kit.
Fit the RLT600 Leg Kit as shown in their instructions. QMHD05 must be purchased to fit Heavy Duty Bars.

Issue: 01


Document No: R577

Prepared: Kayle Everett



RHINO-RACK QMFK01

| Item | Component Name | Qty | Part No. |
|------|------------------|-----|----------|
| 1 | M6 Nut with Foam | 8 | N018 |
| 2 | Instructions | 1 | R577 |



1
Move to the tub of the vehicle. Remove the rubber plugs closest to the cabin in the tracks on either side of the tub.

2
With the plugs removed, slide four M6 nuts in both sides, foam side down.

3
QMDHD05 Fit Kit.
Fit the RLT600 Leg Kit as shown in their instructions. QMHD05 must be purchased to fit Heavy Duty Bars.

Issue: 01


Document No: R577

Prepared: Kayle Everett



RHINO-RACK QMFK01

| Item | Component Name | Qty | Part No. |
|------|------------------|-----|----------|
| 1 | M6 Nut with Foam | 8 | N018 |
| 2 | Instructions | 1 | R577 |



1
Move to the tub of the vehicle. Remove the rubber plugs closest to the cabin in the tracks on either side of the tub.

2
With the plugs removed, slide four M6 nuts in both sides, foam side down.

3
QMDHD05 Fit Kit.
Fit the RLT600 Leg Kit as shown in their instructions. QMHD05 must be purchased to fit Heavy Duty Bars.

Issue: 01


Document No: R577

Prepared: Kayle Everett



RHINO-RACK QMFK01

| Item | Component Name | Qty | Part No. |
|------|------------------|-----|----------|
| 1 | M6 Nut with Foam | 8 | N018 |
| 2 | Instructions | 1 | R577 |



1
Move to the tub of the vehicle. Remove the rubber plugs closest to the cabin in the tracks on either side of the tub.

2
With the plugs removed, slide four M6 nuts in both sides, foam side down.

3
QMDHD05 Fit Kit.
Fit the RLT600 Leg Kit as shown in their instructions. QMHD05 must be purchased to fit Heavy Duty Bars.

Issue: 01


Document No: R577

Prepared: Kayle Everett



RHINO-RACK QMFK01

| Item | Component Name | Qty | Part No. |
|------|------------------|-----|----------|
| 1 | M6 Nut with Foam | 8 | N018 |
| 2 | Instructions | 1 | R577 |



1
Move to the tub of the vehicle. Remove the rubber plugs closest to the cabin in the tracks on either side of the tub.

2
With the plugs removed, slide four M6 nuts in both sides, foam side down.

3
QMDHD05 Fit Kit.
Fit the RLT600 Leg Kit as shown in their instructions. QMHD05 must be purchased to fit Heavy Duty Bars.

Issue: 01

Document No: R577

Prepared: Kayle Everett