
The ARB stretcher quick fold provides quick setup of your campsite, and you enjoying what you went there for.... relaxing. The ARB stretcher quick fold can be used on its own or with the single ARB Skydome swag. Its strong steel construction provides up to 150kg of support and its anti rock feature will minimise the feeling of sleeping on a boat while your perched-up high above the ground. Keeping your boots and other essential items stored off the ground and safe from the creepy crawlers of the night, is the quick connect boot bag. When finished your stretcher packs up quick and easy and stores into its rugged storage bag ready for your next adventure.



## <u>Setting up.</u>

- 1. The stretcher can be setup by removing from the storage bag and standing up with the rounded center handles facing up.
- 2. By grabbing the ends of the stretcher carefully pull outwards and to fully extend the stretcher.
- 3. Move to the center of the stretcher and push down on the handle area to allow the stretcher to position it self flat, make sure the stretcher is fully flat before using the stretcher or setting up your swag.
- 4. Clip on your storage/boot bag to use.
- 5. Attaching a swag Use the included strap with hooks to connect to left peg point on swag, pass the strap underneath the stretcher to attach then to the right peg point,
- 6. Tighten the strap only firmly, this strap dose not need to be over tightened.

Packing up

- 1. Unclip and remove your storage/boot bag and swag, press the storage bag flat and lay in between your center handles on the stretcher.
- 2. Packing up is the reverse, make sure to grab your handles dead center and pull upwards with one of your feet on the metal foot stand.
- 3. The stretcher should fold together and reform the rectangle to store in your carry bag.

Note – if the stretcher dose not fold back up this could be caused by a leg getting caught in the folding mechanism, extend back to flat and make sure you are pulling dead center on the handles to align the folding mechanism correctly.

## Warranty period 2 years

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If this product requires warranty, please return to your closest ARB store accompanied with your receipt of purchase. Warranty period of 2 years from Date of purchase applies to this product.